Antenna Extension Instructions

This antenna extension can be used if the signal of the GPRS module is not strong enough. It can extend the antenna by approximately 2m (6ft.), and includes a mounting bracket (see reverse for installation instructions).



Installation

- 1. Slide the antenna extension into the top of the mounting bracket, and then screw it in.
- 2. Tighten the nut to hold the antenna extension securely in place.
- 3. Screw in the antenna into the antenna extension.